



# Visor Site module


## TECHNICAL MANUAL

Authorisation management .....	3
Adding an authorisation.....	3
Deleting an authorisation .....	4
Configuring user authorisations.....	5
Via the user window .....	5
In the user creation wizard.....	6



## AUTHORISATION MANAGEMENT

From the Tools menu, select Site module.




A list of necessary authorisations is displayed:


A screenshot of a "Configuration" dialog box titled "List of necessary authorisations". It contains a table with two columns: "Name" and "Mandatory". A single row is present, showing "Electric" in the Name column and an unchecked checkbox in the Mandatory column. There are "Add" and "Delete" buttons at the top of the list, and "OK" and "Cancel" buttons at the bottom.

## ADDING AN AUTHORISATION

Enter text in the list of authorisations and click on "Add".




The authorisation is added to the list. Tick the "Compulsory" box if needed.



## DELETING AN AUTHORISATION

Choose an authorisation to be deleted from the list and click on "Delete".




The authorisation will be deleted during page validation.



## CONFIGURING USER AUTHORISATIONS

### VIA THE USER WINDOW

Open the user page and go to the "Site module" tab.




**From this tab, you can:**


- + Choose an expiry date for each authorisation.

Based on the entered dates and the current validity dates, one of two messages may be displayed during validation:

- + In the case where the authorisation dates expire before the current validity date:



- + In the case where the current validity date is less than the smallest closest expiry date:



## IN THE USER CREATION WIZARD

When creating users using the wizard, on the page for entering identities, you have the option to enter authorisation expiry dates.

